



# KAMIYA BIOMEDICAL COMPANY

# Human papillomavirus type 16 (HPV16) antibody (IgM) ELISA

For the qualitative determination of human papillomavirus type 16 (HPV16) antibody (IgM) in serum and plasma

# Cat. No. KU-442

For Research Use Only. Not for use in diagnostic procedures.



# **Product Information** Human papillomavirus type 16 (HPV16) antibody (IgM) ELISA Cat. No. KU-442

# **INTENDED USE**

The Human papillomavirus type 16 (HPV16) antibody (IgM) ELISA is for the qualitative determination of human papillomavirus type 16 (HPV16) antibody (IgM) in serum and plasma. For research use only. Not for use in diagnostic procedures.

# PRINCIPLE

This assay employs the gualitative enzyme immunoassay technique.

The microtiter plate provided in this kit has been pre-coated with antigen. Samples are pipetted into the wells with anti-human IgM conjugated Horseradish Peroxidase (HRP). Any antibodies specific for the antigen present will bind to the pre-coated antigen. Following a wash to remove any unbound reagent, a substrate solution is added to the wells and color develops in proportion to the amount of human HPV16 antibody (IgM) bound in the initial step. The color development is stopped and the intensity of the color is measured.

# PERFORMANCE

#### Specificity

This assay has high sensitivity and excellent specificity for detection of human HPV16 antibody (IgM). No significant cross-reactivity or interference between human HPV16 antibody (IgM) and analogues was observed.

Note: Limited by current skills and knowledge, it is impossible for us to complete the cross-reactivity detection between human HPV16 antibody (IgM) and all the analogues, therefore, cross reaction may still exist.

#### Precision

#### Intra-assay Precision (Precision within an assay): CV% <15%

Three samples of known concentration were tested twenty times on one plate to assess.

#### Inter-assay Precision (Precision between assays): CV% <15%

Three samples of known concentration were tested in twenty assays to assess.

## Limitations of the Procedure

- For research use only. Not for use in diagnostic procedures.
- The kit should not be used beyond the expiration date on the kit label. •
- Do not mix or substitute reagents with those from other lots or sources.
- Any variation in operator, pipetting technique, washing technique, incubation time or temperature. and kit age can cause variation in binding.
- This assay is designed to eliminate interference by soluble receptors, binding proteins, and other • factors present in biological samples. Until all factors have been tested in the immunoassay, the possibility of interference cannot be excluded.

# **COMPONENTS**

Reagents	Quantity
Coated assay plate	1 (96 wells)

# K-ASSAY®

Negative Control	1 x 800 μL
Positive Control	1 x 800 μL
HRP-conjugate (100X concentrate) HRP-conjugate Diluent	1 x 120 μL 1 x 20 mL
Sample Diluent	2 x 20 mL
Wash Buffer (25X concentrate)	1 x 20 mL
TMB Substrate	1 x 10 mL
Stop Solution	1 x 10 mL
Adhesive Strip (For 96 wells)	4
Instruction manual	1

# STORAGE

Unopened kit: Store at 4 °C. Do not use the kit beyond the expiration date.

Opened kit: May be stored up to 2 weeks at 4 °C.

# MATERIALS REQUIRED BUT NOT SUPPLIED

- 1. Microplate reader capable of measuring absorbance at 450 nm, with the correction wavelength set at 540 nm or 570 nm.
- 2. An incubator which can provide stable incubation conditions up to  $37 \degree \pm 0.5 \degree$ .
- 3. Squirt bottle, manifold dispenser, or automated microplate washer.
- 4. Absorbent paper for blotting the microtiter plate.
- 5. 100 mL and 500 mL graduated cylinders.
- 6. De-ionized or distilled water.
- 7. Pipettes and pipette tips.
- 8. Test tubes for dilution.

# Precautions

The Stop Solution provided with this kit is an acid solution. Wear eye, hand, face, and clothing protection when using this material.

# SAMPLE COLLECTION AND STORAGE

#### Serum

Use a serum separator tube and allow samples to clot for two hours at room temperature or overnight at 4 °C before centrifugation for 15 minutes at 1,000 x g. Remove serum and assay immediately or store samples in aliquot at -20 °C or -80 °C for later use. Avoid repeated freeze/thaw cycles.

#### Plasma

Collect plasma using citrate, EDTA, or heparin as an anticoagulant. Centrifuge for 15 minutes at 1,000 g within 30 minutes of collection. Assay immediately or aliquot and store samples at -20 °C. Avoid repeated freeze-thaw cycles.

# SAMPLE PREPARATION

Serum and plasma samples require a 2,000-fold dilution into Sample Diluent. The suggested 2,000-fold dilution can be achieved by adding 2  $\mu$ L sample to 98  $\mu$ L of Sample Diluent first, then complete the 2,000-fold dilution by adding 6  $\mu$ L of this solution to 234  $\mu$ L of Sample Diluent.

Note:

# K-ASSAY®

- 1. Kamiya Biomedical Company is only responsible for the kit itself, but not for the samples consumed during the assay. The user should calculate the possible amount of the samples used in the whole test. Please reserve sufficient samples in advance.
- Samples to be used within 5 days may be stored at 4°C, otherwise samples must be stored at -20°C (≤1 month) or -80°C (≤2 months) to avoid loss of bioactivity and contamination.
- 3. Grossly hemolyzed samples are not suitable for use in this assay.
- 4. If the samples are not indicated in the manual, a preliminary experiment to determine the validity of the kit is necessary.
- 5. Influenced by the factors including cell viability, cell number and also sampling time, samples from cell culture supernatant may not be detected by the kit.
- 6. Fresh samples without long time storage are recommended for the test. Otherwise, protein degradation and denaturalization may occur in those samples and finally lead to wrong results.

# **REAGENT PREPARATION**

#### Note:

- 1. Kindly use graduated containers to prepare reagent. Please don't prepare the reagent directly in the Diluent vials provided in the kit.
- 2. Bring all reagents to room temperature (18-25°C) before use for 30 minutes.
- 3. Distilled water is recommended to be used to make the preparation for reagents or samples. Contaminated water or container for reagent preparation will influence the detection result.

#### Wash Buffer (1x)

If crystals have formed in the concentrate, warm up to room temperature and mix gently until the crystals have completely dissolved. Dilute 20 mL of Wash Buffer Concentrate (25x) into deionized or distilled water to prepare 500 mL of Wash Buffer (1x).

#### HRP-conjugate (1x)

Centrifuge the vial before opening.

**HRP-conjugate** requires a 100-fold dilution. A suggested 100-fold dilution is 10 µL of **HRP-conjugate** + 990 µL of **HRP-conjugate Diluent**.

# ASSAY PROCEDURE

Bring all reagents and samples to room temperature before use. Centrifuge the sample again after thawing before the assay. It is recommended that all samples and controls be assayed in duplicate.

- 1. Prepare all reagents, and samples as directed in the previous sections
- 2. Determine the number of wells to be used and put any remaining wells and the desiccant back into the pouch and seal the ziploc, store unused wells at 4°C.
- 3. Set a blank well without any solution.
- 4. Add 100 µL of Negative Control, Positive Control or diluted Sample per well.
- 5. Cover with the adhesive strip provided. Incubate for 30 minutes at 37 °C.
- 6. Aspirate each well and wash, repeating the process two times for a total of three washes. Wash by filling each well with Wash Buffer (200 μL) using a squirt bottle, multi-channel pipette, manifold dispenser, or autowasher, and let it stand for 2 minutes, complete removal of each step is essential to good performance. After the last wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against clean paper towels.
- 7. Add 100 µL of **HRP-conjugate (1X)** to each well (not to Blank!). Cover the microtiter plate with the adhesive strip. Incubate for 30 minutes at 37 ℃.
- 8. Repeat the aspiration/wash process for five times as in step 6.
- 9. Add 90 µL of TMB Substrate to each well. Incubate for 20 minutes at 37 °C. Protect from light.
- 10. Add 50  $\mu$ L of Stop Solution to each well, gently tap the plate to ensure thorough mixing.
- 11. Take blank well as zero, determine the optical density of each well within 10 minutes, using a microplate reader set to 450 nm.

#### \*Samples may require dilution. Please refer to the Sample Preparation section.

#### Note:

# K-ASSAY®

- 1. The final experimental results will be closely related to operation skills of the end users and the experimental environments.
- 2. Sample or reagents addition: Please carefully add samples to wells and mix gently to avoid foaming. Do not touch the well wall. For each step in the procedure, total dispensing time for addition of reagents or samples to the assay plate should not exceed 3 minutes. This will ensure equal elapsed time for each pipetting step, without interruption. Duplication of all samples, although not required, is recommended. To avoid cross-contamination, change pipette tips between sample additions, and between reagent additions. Also, use separate reservoirs for each reagent.
- 3. Incubation: To ensure accurate results, proper adhesion of plate sealers during incubation steps is necessary. Do not allow wells to sit uncovered for extended periods between incubation steps. Once reagents have been added to the well strips, DO NOT let the strips DRY at any time during the assay. Incubation time and temperature must be controlled.
- 4. Washing: The wash procedure is critical. Complete removal of liquid at each step is essential to good performance. After the last wash, remove any remaining Wash Solution by aspirating or decanting and remove any drop of water and fingerprint on the bottom of the plate. Insufficient washing will result in poor precision and falsely elevated absorbance reading. When using an automated plate washer, adding a 30 second soak period following the addition of wash buffer, and/or rotating the plate 180 degrees between wash steps may improve assay precision.
- 5. Controlling of reaction time: Observe the change of color after adding TMB Substrate (e.g. observation once every 10 minutes), if the color is too deep, add Stop Solution in advance to avoid excessively strong reaction which will result in inaccurate absorbance reading. TMB Substrate should change from colorless or light blue to gradations of blue.
- 6. TMB Substrate is easily contaminated. TMB should remain colorless or light blue until added to the plate. Please protect it from light.
- 7. Stop Solution should be added to the plate in the same order as the TMB Substrate. The color developed in the wells will turn from blue to yellow upon addition of the Stop Solution. Wells that are green in color indicate that the Stop Solution has not mixed thoroughly with the TMB Substrate.

# CALCULATION OF RESULTS

For calculation the valence of human HPV16 antibody (IgM), compare the sample well with control. While ODsample  $\geq$ 2.1 x ODnegative: Positive While ODsample < 2.1 x ODnegative: Negative

## FOR RESEARCH USE ONLY. Not for use in diagnostic procedures.

# KAMIYA BIOMEDICAL COMPANY

12779 Gateway Drive, Seattle, WA 98168 Tel: (206) 575-8068 Fax: (206) 575-8094 Email: LifeScience@k-assay.com www.k-assay.com